



Thank you for purchasing this product. Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment.





Before You Assemble: Please read all instructions carefully before beginning assembly. It is recommended that 2 people work together during assembly to prevent personal injury and to ensure that heavy or cumbersome parts are not damaged during the process.

CAUTION: For your safety, this product requires two people to lift.

PLEASE NOTE: Screws may loosen over time with use and periodically require tightening.


PUB TABLE PART LIST

PART	DRAWING	DESCRIPTION	QTY
A		TABLE TOP	1
B		TABLE LEGS	4



PART	DRAWING	DESCRIPTION	QTY
H1		BOLT (Ø5/16" * 2-9/16")	8
H2		SPRING WASHER (Ø5/16")	8
H3		FLAT WASHER (Ø5/16")	8
H4		ALLEN KEY 4mm	1

NOTE: If needed, only part H1 - H4 are available for replacement.

ADDITIONAL TOOLS REQUIRED: PHILLIPS HEAD SCREWDRIVER 




COMPLETED PUB TABLE ASSEMBLY




MADE IN VIET NAM

STEP 1 Please lay the Table top on a soft, clean surface to assemble. Do not overtighten the bolts. Make sure you use the lock washers to ensure the bolts stay fastened. Do not use an impact drill. Please only assemble bolt and washers with included H4 tool.



STEP 2

NOTE: Do not let table stand on one leg when turning over the table.



PLEASE NOTE: Screws may loosen over time with use and periodically require tightening.